

# RT-U43C0 Programming Codes

## TV's

Admiral – 107, 030, 061, 193, 056

Adventura – 060, 185

Aiko - 106

Aiwa – 135

Akai – 044

Alaron - 193

Amark – 007, 086

Ambassador - 191

Ampro - 112

Amstrad – 006

Anam - 194, 069, 088, 089, 093, 111, 120, 125, 134

AOC – 033, 044, 070

Audiovox – 106, 194, 465, 111

Baysonic - 194

Belcor – 033

Bell & Howell – 030, 168

Bradford - 194

Brocksonic – 250, 477, 054

Brockwood – 192

Candle – 066, 044, 070, 027, 052

Carnivale - 044

Carver - 068

Celebrity - 014

Centurion– 040, 051

Cineral - 106, 465

Citizen – 060, 044, 070, 074, 106, 027, 052, 059

Concerto – 070, 051, 192

Contec – 194, 020

Coronado – 007

Craig – 194, 134

Crosley - 068

Crown – 194, 007

Curtis Mathes – 180, 030, 044, 061, 065, 068, 070, 074, 107, 159, 168, 465, 040

CXC - 194

Daewoo – 106, 465, 027, 039, 051, 090, 091, 092, 094, 101, 102, 108, 114, 118, 121, 123, 130

Daytron – 192, 051, 040

Denon - 159

Dumont – 031, 192

Electro Home – 051, 192

Electro Band - 014

Elektra – 002

Emerson – 250, 168, 191, 192, 193, 194, 296, 477, 007, 008, 012, 054, 108  
Envision – 044, 051, 192  
Fisher – 168, 028  
Fujitsu - 193  
Funai – 185, 193, 194  
Futuretech - 194  
GE – 035, 061, 065, 107, 149, 192, 296, 465, 005, 019, 027, 033, 037, 046, 051, 055  
Gibralta – 007, 025, 027, 040, 051, 059, 058, 192  
Gibralter - 031, 044  
Goldstar(LG) – 044, 070, 192, 124, 007, 027, 040, 059, 058  
Gradiente - 067, 070  
Grundig – 059  
Grunpy - 193, 194  
Hall Mark – 192, 051  
Harley Davidson - 193  
Harvard - 194  
Hitachi – 070, 159, 007, 027, 049, 051, 085, 098, 100  
Infinity - 068  
Inkel – 075  
JC Penney – 005, 027, 037, 051, 041, 035, 044, 168, 192  
JCB - 014  
JVC – 067, 077, 080, 132  
Kawasho – 051, 192  
KEC - 194  
Kenwood -044  
Kloss - 060  
KMC – 007  
KTV – 044, 194, 007, 029, 059  
Kurazai – 030  
Lodgenet – 030  
Logik - 030  
Luxman – 070, 027, 051, 192  
LXI – 061, 068, 168, 170, 192, 006, 056, 105  
Magnavox (Philips) – 044, 068, 193, 001, 005, 007, 026, 027, 052, 048, 081, 192  
Majestic – 030  
Marantz – 044, 068, 076  
Matsushita - 264  
Megatron – 159, 192, 086  
Memorex – 030, 070, 164, 168, 192, 264  
MGA/Mitsubishi – 033, 044, 164, 192, 107, 027, 040, 051, 076, 084  
Midland - 031, 061, 065, 149, 053  
Minutz - 035  
Montgomery Ward – 007, 037, 040, 056, 081  
Motorola - 107, 069  
MTC - 044, 070, 074  
Multitech - 194  
NAD - 180, 170, 192

NEC – 044, 070, 027, 040, 101  
Nikko - 044, 106, 192  
NTC - 106  
Onwa - 194  
Optimus - 180, 168, 264  
Optonica - 179, 107  
Orion – 250, 193, 477, 013, 032, 045, 047, 078  
Panasonic – 065, 264, 019, 021, 024  
Penney - 035, 044, 061, 065, 070, 074, 149, 170, 192, 033  
Philco – 044, 068, 159, 477, 001, 007, 027, 052, 081  
Philips - 068  
Philips (Magnavox) – 001, 027, 081  
Pilot – 044, 059, 097, 192  
Pioneer – 180, 103  
Portland – 106, 007, 027  
Prism - 065  
Proscan – 061, 055, 073, 082, 112  
Proton – 192, 126, 128  
Pulsar – 031, 192  
Quasar – 179, 065, 264, 019  
Radio Shack – 179, 044, 061, 070, 168, 192, 194  
Realistic – 179, 044, 070, 168, 192, 194, 012  
RCA – 061, 104, 149, 065, 107, 022, 027, 046, 055, 072, 073, 082  
Runco - 053, 031, 044  
Sampo – 044, 040  
Samsung – 044, 070, 074, 192, 007, 020, 040, 119, 129  
Sansei - 465  
Sansui - 477  
Sanyo – 168, 002, 028, 071, 133  
Scotch - 192  
Scott – 250, 192, 193, 194, 040  
Sears – 061, 068, 070, 168, 170, 185, 192, 193, 002, 007, 027, 028, 041, 043  
Semivox - 194  
Semp - 170  
Sharp – 179, 107, 007, 009, 023, 056, 064, 096  
Signature - 030  
Signature 2000 – 007, 040, 056, 030, 193  
Sony – 014, 038, 050, 062  
Soundesign – 192, 193, 194, 052  
Squareview – 185, 006  
SSS - 194  
Starlite - 194  
Supre-Macy – 060  
Supreme - 014  
Sylvania – 044, 068, 001, 005, 006, 026, 027, 040, 052, 081, 108  
Symphonic – 185, 006  
Tandy - 107

Tatung – 069, 019  
Technics - 065, 264  
Technol Ace - 193  
Techwood – 065, 070, 027  
Teknika – 030, 068, 070, 074, 106, 164, 193, 194, 001, 007, 027, 052  
Telefunken - 070  
Telarent – 007, 030  
TMK – 070, 191, 192, 027  
Toshiba – 074, 168, 170, 041, 043  
Totevision – 059  
Universal – 027, 035  
Vector Research - 044  
Victor - 067  
Vidikron - 068  
Vidtech – 192, 027  
Viking - 060  
Wards – 030, 179, 035, 044, 068, 070, 192, 193, 027  
White Westinghouse – 193  
XR-1000 – 030  
Yamaha – 044, 033, 027  
York – 040, 070  
Zenith– 030, 031, 106, 025, 034, 036

## **VCR's**

Admiral – 062, 004  
Adventura – 014  
Aiko - 292  
Aiwa – 014, 051, 106  
Akai – 055, 075, 120, 011, 021, 098, 103  
American High - 049  
Asha - 254  
Audio Dynamics – 007, 052  
Bell & Howell – 118, 060  
Broksonic – 016, 135, 198, 225, 030, 048  
Calix - 051  
Canon – 049, 034, 105  
Carver - 095  
CCE - 086, 292  
Cineral - 292  
Citizen – 051, 292, 006, 059, 254  
Colortyme – 052  
Colt - 086  
Craig – 051, 061, 086, 254  
Curtis Mathes – 049, 055, 074, 176, 006, 034, 052  
Cyrernex - 254

Daewoo – 059, 292, 010, 012, 058, 112, 114, 116  
Daytron – 002, 058  
DBX – 007, 052  
Denon - 056  
Dynatech – 014, 106  
Electrohome - 051  
Electrophonic - 051  
Emerex - 046  
Emerson – 014, 016, 051, 057, 075, 135, 198, 222, 225, 226, 292, 003, 022, 040, 091,  
101, 106, 107, 109, 059  
Fisher – 061, 068, 118, 050, 060  
Fuji - 047, 049  
Funai – 014, 106  
Garrard - 014  
GE – 062, 049, 074, 254, 034, 041  
Go Video – 019, 043, 063  
GoldStar (LG) – 051, 052, 006  
Gradiente - 014  
Harley Davidson - 014  
Harman/Kardon – 052  
Harwood - 086  
Headquarter - 060  
H-Q - 061  
Hitachi – 014, 055, 056, 119, 005, 106, 113  
Instant Replay – 017, 034, 049  
JC Penney – 017, 034, 049, 052, 056, 060, 254  
JCL – 049  
Jensen - 055  
JVC – 081, 055, 006, 007, 026, 038, 060, 102  
KEC - 051, 292  
Kenwood – 081, 052, 055, 006, 007, 060, 106  
KLH - 086  
Kodak - 049, 051  
Lloyd's - 014, 222  
Lloyd – 106  
Logik – 086  
LXI – 051, 106  
Magnasonic - 292  
Magnavox (Philips) – 014, 049, 053, 095, 034, 106  
Magnin - 254  
Marantz – 049, 095, 006, 052, 060  
Marta – 051  
Matsui – 094  
Matsushita - 049, 176  
MEI - 049  
Memorex – 060, 062, 014, 049, 051, 053, 061, 118, 176, 254, 034, 104, 106, 110  
MGA (Mitsubishi) - 057, 075, 254

MGN Technology - 254  
Minolta - 056, 119  
Mitsubishi (MGA) – 081, 062, 057, 075, 031, 042  
Montgomery Ward – 009, 014, 034, 037, 062, 074  
Motorola - 062, 049  
MTC - 014, 254, 106  
Multitech – 014, 086, 254, 106  
NEC – 081, 052, 055, 118, 007, 060, 070, 071  
Nikko - 051  
Noblex - 254  
Olympus - 049  
Optimus -062, 051, 118, 176  
Orion – 016, 198, 013, 022, 065, 066, 067  
Panasonic – 049, 176, 034, 099  
Pentax – 056, 119  
Philco – 049, 034, 106  
Philips (Magnavox) – 049, 095, 017, 034, 106  
Pilot - 051  
Pioneer – 081, 176, 045  
Portland – 058  
Profitronic - 254  
Proscan – 086, 041, 074  
Protec - 086  
Pulsar - 053  
Quarter - 060  
Quartz – 060, 090  
Quasar – 049, 176, 034  
Radio Shack - 014, 051  
Radix - 051  
Randex - 051  
RCA – 062, 049, 056, 074, 119, 120, 254, 001, 015, 017, 037, 041, 106  
Realistic – 060, 062, 014, 049, 051, 061, 118, 034, 106  
Runco - 053  
Samsung – 059, 254, 021, 039, 098, 108, 111  
Sanky - 062, 053  
Sansui – 081, 014, 055, 093  
Sanyo – 060, 061, 118, 254, 114  
Scott – 057, 059, 135, 198, 255, 226, 003, 031  
Sears – 060, 014, 049, 051, 056, 061, 068, 118, 119  
Semp - 059  
Sharp – 062, 004  
Shintom – 086  
Shogun - 254  
Signature 2000 – 009, 014, 037, 062, 074  
Signer - 086  
Sony – 047, 014, 046, 049, 048, 032  
Soundesign – 106

STS - 056

Sylvania – 014, 049, 057, 095, 015, 017, 018, 034, 042, 049, 054, 065, 073, 106

Symphonic – 014, 106

Tandy – 014, 060, 106

Tashiko – 051

Tatung – 055, 007

TEAC – 014, 055, 007, 106

Technics – 049, 076

Teknika – 014, 049, 051, 030, 106

Thomas – 014

Thomson - 014, 106

TMK – 222, 254, 091

Toshiba – 057, 059, 226, 050, 096

Totevision – 051, 254

Unitech – 254

Vector - 059

Vector Research – 052, 031

Video Concepts – 059, 075, 052

Videosonic - 254

Wards – 062, 014, 049, 056, 061, 074, 086, 095, 226, 254, 006, 106

White Westinghouse - 292

XR-1000 – 014, 049, 086

Yamaha – 052, 007, 060, 106

Zenith – 014, 047, 053, 008, 038

## **DVD PLAYERS**

Denon – 076

GE – 077

Hitachi – 117

JVC – 079

KLH – 134

LG (Goldstar) – 080

Magnavox – 082, 124

Mitsubishi – 083

Panasonic – 084

Pioneer – 085

Samsung – 125

Sharp – 122

Sony – 087

Thomson – 123

Toshiba – 088

Yamaha – 089

Zenith – 089