

# Codes pour programmation des modèles RC-U49C+ & RT-U49C15+

## TV

Admiral - 026, 054, 211, 213

Advent - 072, 094, 425, 447

Adventura - 047

Aiwa - 214

Akai - 053

Amark - 023, 215

Amstrad - 157

Anam - 217, 218, 219, 220, 221, 222, 223

AOC - 053

Apex - 030, 038, 427

Audiovox - 220, 451

Belcor - 073

Bell & Howell - 211, 213

Brocksonic - 165, 167

Brockwood - 073

Candle - 068, 091

Centurion - 095, 107, 108

Citizen - 068, 091, 211, 213, 233

Concerto - 073, 095

Contec - 147

Coronado - 023

Craig - 223

Crown - 023

Curtis Mathes - 016, 054, 107, 108, 211, 213

Daewoo - 051, 068, 073, 095, 158, 159, 189, 191, 194, 196, 197, 198, 200, 202, 204, 205, 206, 207, 209

Daytron - 073, 095, 107, 108

Dell - 448

Dumont - 073

Electro Home - 073, 095

Elektra - 353

Emerson - 016, 023, 053, 064, 103,

139, 158, 159, 164, 165, 166, 167, 168, 169, 392, 400, 401, 402, 408, 415

Envision - 073, 095

ESA - 454

Fisher - 355, 356

Funai - 047, 048, 157, 168, 211

Gateway - 426

GE - 015, 018, 042, 044, 049, 054, 055, 068, 073, 090, 095, 101, 102, 103, 389, 390, 396, 403, 406, 407, 092

Gibralta - 023, 048, 053, 068, 073,  
090, 095, 107, 108, 233, 360  
Goldstar(LG) - 023, 053, 068, 073, 090, 107, 108, 233, 360, 361  
Gradiente - 104  
Grundig - 233  
Go Video - 443  
Hall Mark - 073, 095  
Hitachi - 023, 068, 095, 096, 097,  
098, 099, 100  
Hyundai - 453  
Inkel - 364  
Insigna - 450  
JC Penney - 039, 053, 068, 073, 092, 095, 102, 355  
Jensen - 062  
JVC - 104, 105, 106, 396, 397,410  
Kawasho - 073, 095  
Konka - 445  
KMC - 023  
KTV - 023, 053, 233, 366  
Kurazai - 211, 213  
Lodgenet - 062  
LG (Goldstar) - 023, 053, 068, 073, 090, 107, 108, 233, 360, 361  
Logik - 211, 213  
Luxman - 068, 073, 095  
LXI - 024, 026, 157, 388  
Magnavox (Philips) - 023, 068, 071, 072, 073, 089, 090, 091, 092, 093, 094, 134, 385,  
387, 397, 404  
Majestic - 211, 213  
Marantz - 053, 107, 108, 109  
Megatron - 215  
Memorex - 090, 211, 213, 355, 388,405  
Mitsubishi/MGA - 053, 068, 073, 090, 095, 107, 109, 110, 216, 384,  
394, 395, 398, 399, 417, 108  
Montgomery Ward - 022, 023, 026, 053, 071, 072, 108, 211, 213  
NEC - 028, 068, 090, 108, 200  
Net TV - 426  
Norcent - 455  
Orion - 019, 159, 160, 161, 162,163, 382  
Panasonic - 042, 043, 044, 045, 046, 429  
Philco - 023, 053, 068, 071, 072, 091  
Philips (Magnavox) - 023, 068, 071, 072, 073, 089, 090, 091, 092, 093, 094, 134, 385,  
387, 397, 404  
Pilot - 073, 094, 233  
Pioneer - 111, 144, 383  
Portland - 023, 068  
Proscan - 055, 070  
Proton - 090, 371, 372, 457

Proview - 459  
Pulsar - 073  
Quasar - 044  
Radio Shack - 073  
Realistic - 022, 166, 168  
RCA - 042, 052, 053, 054, 055,  
069, 070, 416, 068  
Sampo - 090, 108  
Samsung - 015, 016, 017, 023, 031, 090, 107, 108, 134, 147,  
151, 153, 386, 411  
Sansui - 423, 424  
Sanyo - 353, 355, 356, 376, 377  
Scott - 090, 108, 168  
Sears - 023, 031, 038, 039, 068,  
353, 355, 356  
Sharp - 016, 022, 023, 024, 025,  
026, 027, 028, 029, 393, 395, 409  
Signature 2000 - 023, 026, 108, 211, 213  
Sony - 014, 020, 021  
Soundesign - 091  
Squareview - 157  
Supre-Macy - 380  
Sylvania - 068, 071, 072, 090, 091, 092, 093, 107, 108, 157, 158, 419, 456  
Symphonic - 047, 157  
Tatung - 044, 446  
Techwood - 068  
Teknika - 023, 068, 072, 091, 168, 213  
Telerent - 023, 213  
Tevion - 065, 414  
TMK - 068, 090  
Tera - 381  
Toshiba - 030, 031, 038, 039  
Totevision - 233  
Universal - 068, 102  
Vidtech - 068  
Viewsonic - 428, 447  
Wards - 068, 090  
White Westinghouse - 211, 408, 449, 458  
XR-1000 - 213  
Yamaha - 068  
York - 090, 108  
Zenith- 047, 048, 049, 050, 051, 391, 405, 406, 434

## **MAGNÉTOSCOPES**

Admiral - 066, 075

Adventura - 025  
Aiwa - 132  
Akai - 269, 275, 336, 351, 352, 354  
Audio Dynamics - 243, 291  
Bell & Howell - 357, 238  
Broksonic - 333, 337, 358, 359  
Canon - 008, 034, 086, 105, 362  
Citizen - 033, 172, 247, 331  
Colortyme - 091, 291  
Craig - 172, 363  
Curtis Mathes - 086, 112, 247, 291  
Daewoo - 033, 343, 344, 345, 346,347  
Daytron - 345, 365  
DBX - 243, 291  
Dynatech - 132  
Emerson - 033, 086, 132, 326, 327,331, 332, 333, 334, 335, 336, 337, 338, 339, 340, 341, 342  
Fisher - 035, 081, 357, 363  
Funai - 132  
GE - 086, 172, 174, 170  
Go Video - 348, 349, 350  
GoldStar (LG) - 247, 331  
Harman/Kardon - 291  
Hitachi - 078, 132  
Instant Replay - 086  
JC Penney - 078, 086, 172, 238, 291  
JCL - 086  
JVC - 120, 128, 243, 247, 250, 253, 238  
Kenwood - 120, 132, 238, 243, 247  
LG (Goldstar) - 247, 331  
Logik - 367  
Lloyd - 132  
LXI - 132, 331  
Magnavox (Philips) - 086, 132, 183  
Marantz - 086, 172, 183, 238, 247,291  
Marta - 331  
Matsui - 368  
Memorex - 132, 238, 331, 363, 369,370  
Mitsubishi - 255, 258  
MTC - 132, 172  
Montgomery Ward - 066, 170, 173, 373  
Multitech - 132, 172, 367  
NEC - 120, 238, 243, 291, 374, 375  
Orion - 322, 326, 327, 328, 329,330  
Panasonic - 112, 117, 430, 086  
Pentax - 078  
Philco - 086, 132, 183

Philips (Magnavox) - 086, 132, 083  
Pioneer - 078, 120, 263  
Portland - 345  
Proscan - 170, 174  
Quartz - 238, 178  
Quasar - 112  
RCA - 078, 132, 141, 170, 172, 173, 174, 086  
Realistic - 066, 132, 238, 363  
Samsung - 269, 271, 275, 276, 278  
Sansui - 120, 367, 379  
Sanyo - 238, 346, 357, 363  
Scott - 033, 332, 367  
Sears - 035, 078, 238, 331, 363  
Sharp - 066, 075  
Shintom - 367  
Signature 2000 - 066, 170, 173, 373  
Sony - 056, 058, 060  
Soundesign - 132  
Sylvania - 086, 132, 141, 183, 184, 322, 324, 420  
Symphonic - 132  
Tandy - 132, 238  
Tashiko - 331  
Tatung - 243  
TEAC - 132, 243  
Technics - 086  
Teknika - 132, 331, 359  
Thomas - 132  
TMK - 338  
Toshiba - 033, 035, 078, 081  
Totevision - 172, 331  
Unitech - 172  
Vector Research - 291  
Video Concepts - 132, 291  
Wards - 066, 132, 172, 247, 331  
XR-1000 - 367  
Yamaha - 132, 243, 291, 238  
Zenith - 058, 120, 122, 128, 132,  
435

## **LECTEURS DVD**

Apex Digital - 193, 227  
B144 - 146  
Denon - 201, 203  
DVD-Video - 199  
ECA - 156

GE - 150, 152, 156, 172  
Goldstar (LG) - 129, 133, 135, 179, 260  
Gradiente - 212, 234  
Harman Kardon - 256, 259  
Hitachi - 149  
JVC - 177, 179  
Kenwood - 228  
KLH - 248, 252  
LG (Goldstar) - 129, 133, 135, 179, 260  
Magnavox - 138, 143, 146  
Marantz - 270  
Mintec - 432  
Mitsubishi - 181, 185  
NAD - 246  
Onkyo - 085, 244  
Panasonic - 115, 118, 121, 124, 431  
Pioneer - 125, 187, 188  
Proceed - 236  
Samsung - 192, 224, 225  
Sharp - 034, 076, 077, 079  
Sony - 040, 059, 061, 436  
Sylvania - 421  
Thomson - 156, 237  
Toshiba - 082, 085, 087, 113  
Yamaha - 121, 124, 210  
Zenith - 129, 133, 135

## **LECTEURS CD**

ADC - 318  
Akai - 249, 261  
Aiwa - 176  
Carver - 176, 155  
Crown - 154  
Denon - 273  
Fisher - 230, 274  
Goldstar(LG) - 308  
Harman/Kardon - 315  
JVC - 297  
Kenwood - 131, 176, 274, 289, 299  
Krol - 176  
Magnavox (Philips) - 037, 084, 119, 296  
Mission - 176  
Mitsubishi - 245, 249  
NAD - 182, 231, 290  
Nakamichi - 264, 319  
NEC - 235

NSM - 176  
Onkyo - 300  
Panasonic - 184, 266, 437  
Philips (Magnavox) - 037, 084, 119, 296, 433  
Pioneer - 116, 127  
Quasar - 184  
Radio Shack - 186, 190, 266, 279, 289  
RCA - 295, 037, 119  
Sanyo - 230, 309  
SAE - 176  
Scott - 186  
Sharp - 288, 289  
Sony - 067, 292, 293  
Soundesign - 148, 242, 311, 320  
STS - 318  
Sylvania - 084  
Teac - 186  
Technics - 184, 208, 317  
Toshiba - 290  
Yamaha - 280

## **Récep/ampli**

Adcom - 325  
Aiwa - 301  
Akai - 142  
Bose - 302, 440  
Carver - 155, 180  
Denon - 262, 307  
Everquest - 136  
Fisher - 063, 180  
Fosgate Audionics - 305  
Goldstar(LG) - 036  
Harman/Kardon - 130, 257, 305, 306  
Hitachi - 240  
Jensen - 140  
JVC - 114, 241  
Kenwood - 063, 277, 444  
LG (Goldstar) - 036  
Luxman - 281  
Magnavox - 080  
Marantz - 282, 283, 284, 285  
NAD - 286  
Onkyo - 126, 171, 304  
Optimus - 142, 229, 321  
Panasonic - 032, 074, 438, 441  
Parasound - 323

Philips (Magnavox) - 080  
Pioneer - 123, 137, 251, 298  
Quasar - 032  
Radio Shack - 229, 267  
RCA - 439  
Realistic - 226, 268  
Rotel - 310  
Sansui - 283  
Sanyo - 195  
Scott - 272  
Sharp - 294  
Sherwood - 229, 267  
Sony - 041, 057, 232, 287, 442  
Soundesign - 083, 088, 239, 265  
SSI - 313  
Taekwang - 142  
Teac - 314, 316  
Technics - 032  
Victor - 114, 241  
Wards - 063  
Yamaha - 145, 254, 303  
Zenith - 036, 083, 088, 239, 265