



Programming codes for the Helix voice remote

Audio amplifiers and receivers

A to C	
Accurian	31609
ADC	30531
Aiwa	30121, 31641, 30158, 30189
Alco	31390
Altec Lansing	31485, 32720, 30269
AMC	31077
Anam	31609
Apex Digital	31774, 31257, 31430
Arcam	31289, 30269, 30189, 31189, 32241
Arvani	32454
Atlantic Technology	33973
Audio Blast	31289
Audio Control	31289
Audio Net	30269, 32138
Audio Research	31289
Audio Solutions	33622



AudioSource	33721
Audiotronic	31189
Audiovox	31390, 33091
Aura	32454
B & W	33965, 32441, 33943
Bel Canto Design	32041
Bose	31629, 31933, 33708, 31229, 30674, 31357
Boston Acoustics	31840, 33698
Bowers & Wilkins	33965, 32441, 33943
Cambridge Audio	32138, 30269
Capetronic	30531
Carver	30189, 30269, 30360, 30121, 31189, 31289
Classé	31461, 31915
Coby	31389, 32748, 33137, 32698, 33218
Current Audio	31935
Curtis	31389, 33942
Curtis Mathes	30823
Cyrus	32138



D to O	
Definitive Technology	33645
Denon	32857, 33347, 31360, 31104, 32516, 32134, 32279, 32706, 34025, 32247, 32502, 31142, 31289
Durabrand	31561, 31568
Dynavox	33231
Dynex	32971, 33951
Emotiva	33763, 34059, 34100, 34101, 34102
Energy	33915
Epworth	30121, 31641, 30158, 30189
Fisher	30360
Focal	34021
Fosgate	33973
Gateway	31567, 31905
GE	30078, 33297
General Electric	30078, 33297
Go Video	31868
GPX	31389, 33214
Haier	33516
Halcro	31934, 31289, 32138
Harman/Kardon	32241, 30110, 32443, 31304, 30892, 32660, 33756, 31831, 30189, 33045, 33517, 32670
Hitachi	30360



iLive	33175
iLuv	33183
Inkel	32966, 33120, 31567
Insignia	33951, 32175, 32169, 32472, 32966, 31030, 32929, 31751, 31869, 31077, 32126
Integra	31805, 32929, 33992, 31320, 32730, 30135, 31298
iSymphony	32018
Jamo	33915
JBL	33756, 32241, 30110, 33535
Jensen	31389
JVC	32331, 31676, 30074, 33049, 31495, 33167, 30531, 30331
Kenwood	31570, 30027, 31027, 31313, 30186, 32197
KLH	31412, 31390, 32126
Klipsch	33915, 33092
Koss	31497
Krell	31837, 32138
Left Coast	30892
Lenoxx	31561, 31437
LG	32197, 33217, 32676, 32284, 31869
Linn	30269, 30189, 31289
Liquid Video	31497
Logitech	31485



Magnavox	30189, 30531, 31831, 33282, 30269, 31189
Marantz	31289, 32138, 30189, 30269, 30892, 31189, 31831, 33347
Mark Levinson	31483
Martin Logan	33526
McIntosh	30619, 31289
MCS	30531
Memorex	31568
Micromega	31189
Musicmagic	30189
Myryad	31831, 31189
NAD	30320, 31609
Nakamichi	31313
New Acoustic Dimension	30320, 31609
NexxTech	31751
Norcent	31389, 31751
Nova	31389
Onkyo	31805, 30135, 33992, 31320, 32929, 32730, 34041, 31298, 33984, 33312, 33326
Optimus	31023, 30823, 30360, 30186, 30531
Oritron	31497
Outlaw	33973



P to Z	
Panasonic	32967, 33323, 32105, 30309, 31308, 31633, 30308, 33409, 31518, 33767, 31676
Paradigm	33526
Parasound	31934
Philco	31831
Philips	31831, 30189, 33962, 32459, 32289, 31266, 33282, 33652, 32311, 30269, 32675, 33227, 31189, 30892
Philips Magnavox	30189
Pinnacle Speakers	33774, 33728
Pioneer	31935, 31384, 31459, 30823, 31023, 30531, 33956
Polk Audio	33429, 31289, 30269, 30892, 30189, 32270
Proficient	33661
Proscan	31254
RCA	33969, 31254, 33297, 32041, 30531, 32655, 30823, 31935, 31390, 31609, 31459, 32426, 33295, 31023, 31511, 30360, 33091, 33363
Regent	31568, 31437
REL Acoustics	32675
Rio	31869
Rotel	32331
Samsung	31868, 32660, 32137, 31304
Samsung Harman/Kardon	32660
Sansui	30189, 30531
Sanyo	30360, 33282



Sharp	30186, 33736, 33097, 33929
Sharper Image	32023
Sherbourn	33763
Sherwood	31567, 31077, 32169, 33120, 31905, 33175, 32929, 32966
Sherwood Newcastle	31567, 32169
Simaudio	30269
Sonic	32284
Sonic Blue	31869
Sonos	33919
Sony	32610, 30158, 31622, 32172, 31759, 31758, 33487, 33903, 33114
Soundesign	30078
SpeakerCraft	33661
Stereophonics	31023
Sunfire	31313, 31570
Sungpo	30186, 33736, 33097, 33929
TAD	30823
Teac	31609, 31390, 33992, 31267
Technics	30309, 31308, 30308, 31633, 31518
Techwood	32284
The Gryphon	30269, 32138
The Sharper Image	32023



Thorens	31189
Toshiba	31788, 33627, 31320, 31935
Venturer	31390, 33091
VIZIO	32454
Yamaha	32467, 32458, 32021, 30176, 32061, 31331, 31276, 30376, 31815, 32471, 33333, 31176, 30354, 30186
Zenith	32197, 31869, 32284
ZVOX	32332, 33913, 32334